JM SPACE1

Oil-mist Collector

後置安裝說明

AIR FILTER INSTALLATION INSTRUCTIONS

高速離心物理分離 · 零耗材 · 零衰減 · 極簡運維

創新 · 迎勢贏天下

上海巨孟實業有限公司

安裝步驟
Installation Steps

01 支架鎖固於電機孔位（螺絲 ×4）
Bracket locked to motor holes (screws ×4)



如下圖紅圈所示位置鎖緊。
Tighten at the positions indicated by the red circles below.

02 放上後置
Place the AIR FILTER



將後置濾芯對準底座後平穩放置。
Align the rear filter cartridge with the base and place it smoothly.

03 鎖固頂部螺絲（螺絲 ×1）
Lock the top screw (screw ×1)



鎖緊頂部固定螺絲，確認無鬆動。
Tighten the top fixing screw and check for looseness.

注意事項 / Notes
安裝前請確認設備已斷電，並使用原廠提供之螺絲與支架。 / Ensure power is off before installation and use the original screws and bracket provided.